


Nexus n Wind



**The NX2 server through the multi control or race software has the ability to configure the NMEA data output from the server. This operation is covered in the server manual section 2.6 and the NX2 multi control manual section 12.7. The following NMEA sentences have been chosen to provide the basic log, depth, compass and wind data from the Nx2 server to the Garmin chartplotter.

MWD
MWV
DBT
VHW
MTW
HDM

<p align="center">CONFIDENTIAL</p> <p>This drawing and the specifications contained herein are the property of Garmin Ltd. or its subsidiaries and may not be reproduced or used in whole or in part as the basis for manufacture or sale of products without written permission.</p>		<p align="center">GARMIN®</p> <p align="center">Garmin Ltd. or its subsidiaries c/o Garmin International, Inc. 1200 E. 151st Street Olathe, Kansas 66062 U.S.A.</p>	
		<p>TITLE Schematic, Garmin GPSMAP to Nexus System</p>	
<p>DATE</p>		<p>SIZE B</p>	
<p>DRWN. DAZ</p>		<p>DWG. NO. 970-108</p>	
<p>08/28/2013</p>		<p>REV. A</p>	
		<p>SCALE NONE</p>	
		<p>SHT. 1 OF 1</p>	